

Oakley Sound Systems

**Filtrex II
PCB issue 2**

Analogue Filter Rack

Builder's Guide

V2.4

Tony Allgood
Oakley Sound Systems
Carlisle
United Kingdom

Introduction

This is the Builder's Guide for the issue 2 Filtrex II rack module from Oakley Sound. It contains the schematic description, parts list and testing procedures. For those of you with an issue 1 Filtrex-II board you should ensure that you have the proper Builder's Guide for your board and not this one.

For the User Manual, which includes a brief history about the development of the module, a guide to the front panel controls and some notes about the power pack needed to power your module, please visit the project webpage at:

<http://www.oakleysound/filtrex.htm>

For general information regarding where to get parts and suggested part numbers please see our useful Parts Guide at the project webpage or <http://www.oakleysound.com/parts.pdf>.

For general information on how to build our modules, including circuit board population, mounting front panel components and making up board interconnects please see our Construction Guide at the project webpage or <http://www.oakleysound.com/construct.pdf>.

This is an early version of the documentation. If you do find any errors, even silly little ones, please do let me know either directly by e-mail or via the Forum or mailing list.

Parts List

For general information regarding where to get parts and suggested part numbers please see our useful Parts Guide at the project webpage or <http://www.oakleysound.com/parts.pdf>.

The components are grouped into values, the order of the component names is of no particular consequence.

A quick note on European part descriptions. R is shorthand for ohm. K is shorthand for kilo-ohm. R is shorthand for ohm. So 22R is 22 ohm, 1K5 is 1,500 ohms or 1.5 kilohms. For capacitors: 1uF = one microfarad = 1000nF = one thousand nanofarad.

To prevent loss of the small ‘.’ as the decimal point, a convention of inserting the unit in its place is used. eg. 4R7 is a 4.7 ohm, 4K7 is a 4700 ohm resistor, 6n8 is a 6.8 nF capacitor.

Please note that if you are building a stereo version of this module you will need two Filtrex-II boards. One of them will be built as a Master and the other as a Slave. For the Slave module you should not fit parts marked with a *. Please see later in this document for a suggested method on how to wire the two modules together.

Resistors

All resistors 5% or better 0.25W types. Those items marked with 1% need to be 1% metal film (or better) 0.25W metal film resistors. For the sake of clarity it may be simpler to make all resistors 1% metal film types.

R61 is a +3000ppm/K positive temperature coefficient resistor.

22R	R5, R53, R109, R4, R52, R115, R121, R96, R80, R81, R8, R122
47R	R111, R116, R126
150R, 1%	R51, R54
330R	R10, R18, R19, R13, R17
470R	R12, R20
1K	R11
1K +3000ppm/K	R61
1K5	R117
2K2	R9*, R91, R56, R46, R57
2K2, 1%	R25, R24
2K7	R47
3K	R100
3K9	R1, R15
4K7	R87, R97, R74
4K7, 1%	R41, R43, R30, R34
6K8	R70, R39, R6, R38
10K	R123, R3, R78, R58, R113, R55, R104, R110
10K, 1%	R42, R32, R31, R44
12K	R99

15K	R40, R37, R69
22K	R75, R14, R7, R108, R112
22K, 1%	R28, R27, R22, R23
33K	R16
39K	R107
47K	R85, R29, R26, R35, R71, R36, R124, R33, R82, R79
56K	R59, R60
68K	R65
100K	R125, R101, R120, R73, R68, R88, R114, R119, R98, R92, R93, R76, R72, R84, R89, R95, R94, R118, R66, R67, R64, R45, R83, R103
100K, 1%	R48, R50
220K	R21, R90, R63
330K	R102
470K	R62, R49, R2
680K	R105
1M	R86
3M3	R106, R77

Capacitors

22pF low-K 2.5mm ceramic	C7, C3
33pF low-K 2.5mm ceramic	C48, C28
100pF low-K 2.5mm ceramic	C26
1nF, 100V polyester	C43, C30, C39
68nF, 63V polyester	C12, C13, C14, C15
100nF, 63V polyester	C32, C52, C20, C21, C35, C54, C55, C41, C50*, C38*
470nF, 63V polyester	C5, C24
680nF, 63V polyester	C19, C18, C17, C44
1uF, 63V polyester	C16
2u2, 63V electrolytic	C51, C33
10uF, 35V electrolytic	C37, C22
22uF, 35V electrolytic	C56, C53, C34, C6, C8, C4, C49, C25, C27, C45, C11, C46, C36, C10
100uF, 25V electrolytic	C42
220uF, 10V electrolytic	C9
1000uF, 35V electrolytic	C47*, C40*
10uF, 35V non polarised elect	C23, C29, C31, C57
22uF, 35V non polarised elect	C1, C2

Non polarised capacitors can sometimes be called bipolar. Unlike ordinary polarised electrolytic capacitors they can be put into the board any way around.

Discrete Semiconductors

BC549 or BC550	Q1-15
1N4002 or 1N4004	D8, D23, D9*, D13*, D14*, D18*, D19*, D24*
1N4148 or 1N914	D1, D2, D3, D4, D5, D6, D11, D12, D15, D16, D17, D20, D21, D22, D25
BAT-42	D7, D10
LED 3mm green	TRIG
LED 3mm red/green	LFO
LED 3mm red	PEAK
LED 3mm yellow	ON

The LFO LED is a bi-colour LED in a water-clear package. Do not fit an ordinary single colour LED in this position.

Integrated Circuits

OPA2134PA	U1, U7
NE5534	U8
TL072	U3, U5, U6, U9, U16
TL074	U4, U10, U14
7815	U15*
7915	U11*
THAT300P	U2
4001	U13
4016	U12

Pots

All pots 16mm Alpha or Alps types.

50K linear dual gang	RESONANCE, GAIN
1M log	UP, DOWN
50K linear	SMOOTH, FREQ, FIZZ, DRY/WET, THRESHOLD, ENVELOPE
10K linear	VOLUME
50K log	LFO-RATE, LFO-DEPTH

Trimmers

22K trimmer	TRIM
470K trimmer	BAL

Switches

SPDT on-on	CONT, AUTO, WAVE
SPDT on-off-on	MODE

Miscellaneous

Leaded ferrite bead	L1
Heatsinks TO-220 clip-on	2 off for U11 and U15
2-way 0.1" KK Molex header	4 off INPUT, SIDE, CV, GATE
3-way 0.1" KK Molex header	1 off OUTPUT
2-way 0.1" KK Molex housing	4 off INPUT, SIDE, CV, GATE
3-way 0.1" KK Molex housing	1 off OUTPUT
16mm Alpha pot brackets	13 off

Off-board Parts

These are fitted to the rear panel

1/4" mono sockets	4 off	Input, Side chain input, CV, Gate
1/4" stereo (TRS) socket	1 off	Output
Suitable power plug	1 off	Power In

I recommend plastic shrouded sockets for both the audio, CV and power sockets. This will reduce the risk of earth loops.

Additional parts required for stereo operation on both boards

2-way 0.1" KK Molex header	2 off	STV, ST-A
2-way 0.1" KK Molex housing	2 off	STV, ST-A
4-way 0.156" KK or MTA header	1 off	MOTM
4-way 0.156" KK or MTA housing	1 off	MOTM

You will also need a power source of some kind. The recommended supply is a wall-wart supplying 15V AC at 300mA minimum. See later for more information.

A small amount of insulated multistrand wire is needed. This will be used to connect the sockets and power supply to the board.

IC sockets are to be recommended, especially if this is your first electronics project. You need eight 8-pin DIL sockets, and six 14-pin DIL sockets. Choose ‘turned pin’ or ‘dual wipe’ types.

Circuit Description

Like many complex analogue circuits the Filtrex-II issue 2 circuit can be split up in to little bits. The first bit we will look at is the pre-amplifier stage on page one of the schematic. The input signal comes in through a small network of passive parts: L1 acts as a filter for radio frequency interference. C5 and R2 act as a high pass filter removing any DC from the input signal. R3 and C26 act as a low pass filter removing any unwanted high frequency components from the input. R3 also protects U1 from possible over voltage.

The pre-amp is built around U1. I have specified the low noise audio op-amp, the OPA2134. The pre-amplifier is a two stage design. The first stage is a non-inverting amplifier whose voltage gain can be varied from 1 to 12. C1 keeps the gain for DC and very low frequency signals at near to one. This prevents any offsets within U1 from being amplified unnecessarily C3 provides a little bit of high frequency roll-off to keep the amplifier stable.

The second stage of the pre-amp is an inverting amplifier. The GAIN pot is used in a slightly offbeat way. It is in both the feedback and the input resistors. This way we can control the gain over a wide range from -0.4 to -10.1. The minus in these numbers shows the inverting properties of the amplifier.

The voltage gain of the two pre-amplifier stages in tandem can be varied from -0.4 to -122. A gain of 0.4 means that the output of the pre-amp is only 40% of the input level. While a gain of 122 means that the output level is 122 times bigger than the input. In audio circles this would normally defined in dB. This pre-amplifier will give you a gain from -8dB to +42dB. Because the pre-amplifier is made from an inverting and non-inverting stage, the overall behaviour is inverting. This means the output is completely out of phase with the input. This is not a problem since the inversion is corrected later on the Filtrex.

Q7 and associating circuitry drive the peak LED. This is designed to light up just as the ladder filter starts to show heavy distortion.

The main audio path continues on to the filter ladder itself via one half of the resonance pot. However, the pre-amp also provides the signal for the 'dry/wet' circuit and the envelope processor. We will deal with these two later.

The filter is based around the traditional ladder as designed originally by Dr. Moog. I have used THAT300 matched NPN array for the top and bottom pairs in the ladder. This minimises control current breakthrough to almost zero. Current breakthrough manifests itself as a copy of the modulating signals on the output. Generally, this is not a good thing. 'BAL' biases the base of the left hand bottom pair (U2, pin 9), via R21, by a small amount to even out any differences within the ladder. This minimises breakthrough still further.

Two of the rungs of the ladder are 'sniffed' by a differential amplifier. Each of these is identical, based around the classic three op-amp implementation. They are all DC coupled, and rely on 'close' matching to remove any DC offset. A differential amplifier is a device that makes larger the voltage difference between two points. In our case, the voltage across the top and bottom filter capacitors. The gain of the differential amplifiers is set higher than normal ladder filters to improve signal to noise ratio in the following mixer stage. C17 and

C18 provide AC coupling of the outputs to remove the slight DC offset from the top differential amplifier.

The resonance in a moog ladder filter is controlled by the level of audio feedback applied to the bottom pair of transistors from the output of the differential amplifier at top rung of the ladder. The level of is typically controlled by the resonance pot, wired as a variable resistor and a trimming resistor, TRIM. It is traditional to use a 50K reverse log pot for the resonance control in the classic moog ladder circuit. When set to a value of 50K this pretty much allows the feedback path to be ignored, and no resonance can be heard. The ‘reverse log law’ is needed so that as you turn the pot the resonance increases smoothly. An ordinary linear law pot would do nothing for most of its travel, and then all the resonance would be introduced in the last quarter of a turn. Not very ‘smooth’ or musical. Unfortunately, 50K reverse log pots are difficult to find and quite expensive.

In the Filtrex-II, we use an 50K linear pot, but we wire it as a potential divider and not as a variable resistor. The drawback of using a pot on its own like this is that it has a variable output impedance and the ladder is therefore unbalanced, the degree of which depends on where the resonance control is set. We get around this by using a buffer on the pot's output. U3, a unity gain voltage follower, or buffer, ‘sniffs’ the voltage at the wiper of the resonance pot and provides a copy at its own output that has a constant impedance.

The resonance pot is a dual gang type too. One gang controls the feedback loop as we have seen, and the other sets the gain of the input. Normally the passband gain of a moog ladder decreases as you turn the resonance up. In other words the volume drops as you increase the resonance. This can be quite a problem for a post processor like the Filtrex. So in the Filtrex, the input level is automatically turned up as resonance increases. Thus the overall effect is of a constant volume at all values of resonance. I thought this was quite clever of me to invent a way of doing this without increasing noise levels. However, I found out later that the very same principle was used in the Roland SH-2000 as long ago as 1974.

The other half of U3 acts again as a voltage follower on the wiper of the gain control part of the resonance pot. This ensures that the ladder's input is fed from a constant resistance no matter where the resonance pot is positioned.

C11 provides the appropriate decoupling and is sufficiently large so as to allow the filter to oscillate above 200Hz or so.

Four inputs control the filter cut-off frequency via an exponential convertor based around U9. The filter frequency can be directly controlled with the FREQ pot via R63. R65 sets the sensitivity of the envelope processor’s output. While R67 does the same job for the LFO. The CV input provides a nominal 1V/octave response, and would normally be accessed via a jack socket on the rear panel.

The exponential convertor is temperature compensated. R61 is the positive temperature coefficient resistor providing an approximate cancellation of the exponential convertor’s inherent temperature coefficient.

Note the two pin header, STV, and R60. These allow two Filtrex-II modules to be ganged together to form stereo processing. There is more about this later in the document, but we can

see that the output of the CV summing amp is present at pin 1, while a second CV input is made available at pin 2. The master Filtrex-II will be sending the CV signal via pin 1 on the STV header to pin 2 on the slave's STV header. This way the master Filtrex-II board will also control the slave's cut-off frequency. It would be expected that the connection be done via a switch so the linking could be turned on or off from the front panel.

The audio path continues from the filter's differential amplifiers by going on to the mixer stage. This is shown on page two of the schematics at the top of the page. The mixer stage is designed to combine the three audio signals created by the Filtrex so far: The first and fourth rung ladder outputs, which will make up the 'fizz' and 'smooth' outputs respectively. And the main pre-amplified signal which will go to the 'wet/dry' balance control.

The two filtered signals go to identical 'reversible attenuator' circuits. U5 is wired as two inverting amplifiers, each with a gain of -1. Each inverted signal is applied to one end of a pot, while the non inverted signal is applied to the other. By simply moving the wiper of the pot to one side or the other determines which signal is dominant. When the wiper is in the middle position the two signals cancel each other out and the voltage is zero. U7a (pins 1, 2, 3) is configured as an inverting summer. This circuit combines the voltages at each wiper. R38 and R39 are deliberately low in value when compared to the 50K of the pots. This loads the relative high impedance output of the pot and warps the law of the pot. This allows the central null point to be more easily found.

U7b (pins 5, 6, 7) in conjunction with the dry/wet pot and R45 form the output balance circuit. This block allows the user to select between the output of the filter mixer or pre-amplified signal. It is easy to see how it works when you consider the action of the wiper moving between one end of its track connected to U7 pin 1 and the other which is connected to the output of the pre-amplifier.

The output of the mixer stage is fed via a DC blocking capacitor to the 'Volume' pot. The wiper of this is connected to the final output amplifier stage. This is a low noise inverting amplifier circuit, based around U8, with a gain of -3.7. The op-amp chosen is the 5534 which is capable of driving larger currents than most ordinary devices. R54 reduces any chance of high frequency ringing in long cable runs and protects against short circuits. Non polar capacitor, C57, and R50 remove any small DC offset voltage present on the output of U8.

Now let us look at the little network R48, R51 and C29. This mimics the output impedance of the main audio output – although the small differences between C29 and C57 and the non zero output impedance of U8 do not allow it to be an exact match at all frequencies. This network connects to pin 2 of the output header which goes to the ring of any connected jack plug. Now if the inserted jack is a mono one the ring terminal will simply be shorted to the sleeve by the action of the jack plug. Thus the output of the Filtrex-II behaves in much the same way as a traditional unbalanced output. However, if you use a TRS plug (a stereo jack plug but carrying only a mono signal) then the audio output of the Filtrex-II appears as a balanced impedance output. This can be used as you would a traditional balanced output signal; with the hot signal being present on the tip, the cold signal on the ring and the ground on the sleeve.

Many balanced output circuits present the audio signal on both the hot and cold connections; the signal on the cold connection being an inversion of the signal on the hot. This alone is

often considered to be a balanced signal but in truth the receiving end of the balanced connection cares not for the absolute signal levels on the hot and cold connections but only the difference between them. And because all balanced input circuits do not have an infinite input impedance the source impedance is very important to this differencing process. By keeping both the hot and cold's source impedance as close in value as possible you maximise the ability of the balanced input's circuitry to reject any unwanted interference on the audio signal.

The advantage over the impedance balanced circuit over the full balanced circuit is two fold: Simplicity – you have less circuitry in the audio pathway to either go wrong or alter the signal in some way. And compatibility – the impedance balanced circuit can be used for both balanced systems and unbalanced systems with no possible problems with stability or short circuits. Now there are EBOS (electronically balanced outputs stage) circuits around that will automatically compensate for unbalanced connections but they do add complexity and may be prone to instability under certain load conditions.

The disadvantage of solely impedance matching is a comparative loss of headroom. The full balanced system has an additional 6dB of output signal to play with. It is the author's opinion that this does not make a great deal of difference in the real world.

If the venerable 5534 is replaced by a more modern single op-amp you should remove C28 as additional compensation will probably not be required. You may also be able to link out the coupling capacitor, C57 and its twin, C29, if the output offset voltage is negligible. R50 and R48 may also be removed in this case.

That completes the description of the audio path. Now let us take a look at the processing circuitry of the Filtrex. Staying on page two of the schematics, the second set of circuits down the page belongs to the full wave rectifier and threshold detector. This takes its input from either the pre-amp output or the external side chain input. The choice is determined by the 'cont' switch.

The switch's wiper leads straight into some amplification based around U14a. This is an inverting amplifier with a gain of -3.3. The main pre-amp is expected to produce a maximum output of around 5Vp-p in normal use, so U14a boosts this signal up to 15Vp-p. The amplified signal is now full wave rectified by the circuitry based around U14b and associating circuitry. Full wave rectification can be described by the mathematical 'absolute' function. In other words, the output of the full wave rectifier (FWR) is always positive. If you present +10V to the input, you will get +10V. But if you present it with -10V you will also get +10V. Likewise, -5V turns into +5V, -3V into +3V. Now if you put an audio signal into this circuit, you will get a series of positive bumps that correspond to the up and downs of the audio signal.

U14d forms a special buffer circuit. This configuration, allows the op-amp to drive medium to high capacitive loads without instability. We also saw it being used in the output amplifier of the Filtrex. The output of the full wave rectifier is therefore protected by the odd load presented by the next set of circuits.

Now, no real time system can recover envelope information without some disadvantage of some sort. Some systems employ the *peak and droop* method. These are fast to respond to sudden changes in loudness or envelope. They work by simply charging a capacitor as fast as

possible from the FWR through a diode. The capacitor is then discharged through a resistor, sometimes variable but often not, causing the stored voltage to droop at a determined rate. However, they are often plagued by ripple when used to process certain types of input signal. Ripple is the bumps from the FWR creeping through to affect the required output. This tends to manifest itself in a ‘buzz’ to the output CV. If you increase the discharge resistor, you can reduce the bumps but this tends to not allow the CV to drop quick enough when the input signal ends.

Another method involves low pass filtering of the FWR output. This leads to less bumps if the correct filter cut-off frequency is chosen, but does lead to longer attack times. There are more complex ways too, involving sample and holds and other clever methods.

In the Filtrex the output of the FWR is passed to a special circuit called the ‘lag processor’. This is cleverly combined with the function of the envelope generator and is described in detail later. At this point I will just say that it functions as a simple low pass filter with controllable rise and fall times.

But let us stay on page two for now. To create a gate signal we need a very fast response. In an ideal world this signal must go high the moment the signal arrives and goes low the moment the signal dies away. In this case I have used the *peak and droop* method. This does give us a fast response as possible, but what about the ripple. Well, ripple is not *that* important here. Remember the gate output only goes high or low. What we have to do is make sure our gate doesn’t ‘rattle’ when it picks up the ripple. In other words, we need our gate to come cleanly on and off with no spurious states as the signal rises and falls.

U14b (pins 5, 6, 7) is a comparator. This is a device based around an op-amp that determines whether a signal is higher than a pre-selected threshold voltage. The threshold voltage is controlled by the user, and is set by the ‘Threshold’ pot. The threshold voltage can be set between 12V and 0.7V. C44 is charged via D15 from the FWR output. D15 allows the capacitor to be charged up, but not discharged, by the FWR’s output. R104 allows the capacitor’s stored peak voltage to droop at a controlled rate.

Most gate extractors provide a gate signal when the voltage on the capacitor is above a certain value. The Filtrex is similar but once the gate does go high, a certain proportion of the opamp’s high level output is fed back, via D16, to keep the input higher. This forces the comparator to stay high longer than it would normally do. This allows more ripple to be present before ‘rattling’ occurs, giving us a cleaner edge to our gates. You don’t have any control over this amount of positive feedback, it is set by the value of R105. A good comparator designs have a little positive feedback anyway, it is called hysteresis, and in our case it is provided by R106. But the additional path via D16 offers a type of one way hysteresis that gives us better high to low gate transitions.

The comparator’s output is fed via D17 to a transistor Q13. This transistor is turned on when the comparator’s output goes positive. D17 protects the transistor from damaging negative output voltages. Q13’s collector will be pulled down to ground when the transistor is turned on. This in turn controls the envelope generator’s logic circuitry described later.

Lets have a look at the third page and the envelope processor itself. This is quite a hard bit to understand.

The heart of this unit is the circuitry based around U10b (pins 5, 6, 7). This, along with the ‘up’ and ‘down’ pots, make up the lag generator. What is a lag generator? Basically it is a capacitor, C37 in this circuit, that can be discharged and charged at a controlled rate. The level to which the capacitor charges to, or discharges to, is determined by the input voltage applied to pin 5 of U10. The voltage across the capacitor will directly control the output of the envelope processor.

U12 is an analogue switch. It is a good old 4016, and this IC is found in hundreds of synth circuits. In the Filtrex, it doesn’t do a great deal other than select which mode the envelope processor is going to be in. The 4016 is controlled by the ‘mode’ switch. For the envelope processor to be in envelope follower, or EF, mode, the FWR output needs to be patched into the lag generator. U12 (pins 6, 8, 9) switches on, and U12 (pins 10, 11, 12) is off. The positive voltage that is being produced by the FWR will now start to charge or discharge C37 up and down. The speed of the charging will be controlled by the ‘up’ pot, and the speed of the discharge will be controlled by the ‘down’ pot. U10c (pins 8, 9, 10) buffers the voltage across C37 to create the positive going EF output signal. U10d (pins 12, 13, 14) inverts this to produce negative going voltages. The ‘envelope’ pot controls the depth of the effect. The position of the pot’s wiper will determine the polarity and the level of the final output signal. D3 and 4, along with R58, create a dead band around zero volts so the pot doesn’t have to be exactly in the middle for no modulation.

In EG mode, U12 is switched over to allow the output of the EG logic circuitry to control the lag generator. The output of this logic circuitry is either high, +7.5V or low, 0V. The logic circuitry can operate in two modes, attack-decay (AD) or attack-release (AR).

Several sources can initiate the attack phase. One is the external ‘gate’ signal. This is a switch type signal that is either at around 0 volts when off, or any positive voltage greater than 3V when on. The Filtrex can easily handle greater voltages, within reason, without damage. D5 protects Q11 from any negative inputs.

Other sources of triggering the attack phase come from the LFO and the threshold detector already discussed in this document. Both of these trigger the unit by pulling the collector of Q11 down to zero via the TRIG bus.

When a positive gate signal arrives, Q11 turns on and pulls its collector down to ground or 0V. This inverse version of the applied gate signal is sent to two destinations. One is another transistor, Q14. This is configured as another inverter. Thus the output of Q14 produces a copy of the gate signal that swings from 0 when off to +15V when on. R86 passes some current back to the first transistor. This creates a type of Schmitt trigger action which makes the transistors change state faster. It therefore allows slowly varying signals to trigger the Filtrex. For example you can use a slow sine wave or aftertouch CV to fire the EG.

The output of Q14 is passed on to a CR network that acts as a differentiator. This circuit produces a positive voltage spike when the gate goes high. The duration of the spike is determined principally by the values of C43 and R93. D12 prevents a negative spike being produced when the gate goes low. The positive spike triggers an RS flip-flop circuit based around two NOR gates, U13.

A flip-flop is a sort of a one bit memory, or latch. Once triggered by a positive going pulse at pin 12, it stays latched. You can only reset it by removing the power or a reset pulse at its other input, pin 9. When the flip-flop is latched, pin 10 goes high and pin 11 goes low. The output at pin 10 is passed via R89 and U12 to the lag generator's input, thus causing C37 to start to charge upwards. R89 is chosen to interact with R73 to give an input signal of 7.5V in the high state.

In any mode, removing the gate will reset the flip-flop. The inverted gate signal from Q11 goes to a second differentiator, C39, R92 and D11. When a gate signal is removed, the positive going edge runs through U13 (pins 1,2,3 & 4,5,6) to reset the flip-flop. Thus removing a gate signal will cause the lag generator's output to fall.

Another way to reset the flip-flop is in the AD mode. This utilises the actual output of the lag generator to control the discharging process. When the output of the lag generator exceeds a certain value, approximately +3.8V, the flip-flop is reset and the output voltage will drop.

This job is performed by a comparator based around U10a (pins 1, 2, 3) and Q10. The output of the lag generator is passed onto the comparator by another analogue switch U12 (pins 1, 2, 13). In AR mode, this is switched off and the input to the comparator is held low by R83. In AD mode, the switch opens to allow the comparator to sniff the output of the lag generator.

When the voltage exceeds +3.8V or so, the comparator's output goes from 0V to +15V. This tells the flip-flop that the attack phase is over and the decay phase is about to start. Pin 10 therefore goes low and C37 is discharged via the 'down' pot.

R69 and R70 set the +3.8V threshold level. R77 with R78 provides a thin slice of positive feedback to force the comparator to switch cleanly... it is another Schmitt trigger again.

The LFO circuit is quite simple. It is on page two of the schematics.

The first TL072 op-amp, U16a (pins 1, 2, 3) forms part of the integrator. Any positive voltage applied to the right of R120 will cause the voltage to fall at the output of the op-amp. The speed at which the voltage falls is controlled by C52 and the size of the voltage applied to R120. If the applied voltage is negative the op-amp's output will rise. It is the integrator's output that will be used as the source for the triangle wave output.

The second half of the TL072 op-amp is used as a Schmitt trigger. Its output is either high at +13V, or low at -13V. If the output of the Schmitt is initially low, it requires +6V at the output of the integrator to make it go high. The integrator will need to produce an output of -6V to make the Schmitt go low again.

To make any oscillator you normally require an output to be fed back into the input. In a standard LFO like this one, the integrator is fed by the output of the Schmitt trigger. Thus, a low at the output of the Schmitt causes the integrator to rise. When the integrator's output reaches a certain point, the Schmitt switches state and the integrator's output falls. The Schmitt trigger changes state once again, and the process repeats itself....

The 'LFO-rate' pot allows a only a controlled proportional of the Schmitt's output voltage to reach the integrator. If the proportion is large, the voltage on R120 is large, and the integrator

sweeps fast. If the proportion is small, the integrator sweeps slowly. R116 sets the minimum speed. Don't be tempted to lower this value any more to get really slow sweeps. Input errors within the integrator op-amp will take over and your LFO won't oscillate any more.

With C52 at 100nF the range of the LFO is about 0.05Hz (one cycle in 20 seconds) to 50Hz. If you make C52 a 220nF capacitor the LFO will be proportionately slower and you will have a range of 0.02Hz to 23Hz.

The square wave output is derived from the Schmitt trigger's output. D25 allows only positive excursions through. R123 and C55 act as a simple low pass filter to round off the waveforms edges a little bit. Very fast edges end up as CV breakthrough on the main audio output and are pretty unpleasant.

The trigger output is simply generated by a transistor, Q12, that turns on when the output of the Schmitt trigger goes high. The 'auto' switch switches the function off by shorting the base to the emitter when not required.

The last thing to describe is the power supply. This is a standard 'three terminal regulator' design straight out of the data book. R96 and C42 provide a decoupled version of +15V for the logic circuitry. The logic circuitry can generate little spikes on the power supply, that could get back into the audio if not decoupled properly. R9 and the 'on' LED provide power supply indication. I have put it on the negative supply only to even up the power drains on both rails.

The Filtrex's power supply can function either with a half wave rectifier for wall warts, or with full wave for internal transformers. This will be covered in more detail later on the document.

Audio and Ground Connections

You are going to need five 1/4" jack sockets, four mono and one stereo, to connect your PCB to the outside world. Each jack is connected to its respective 0.1" headers on the PCB. The stereo jack socket is to be fitted in the Output position. This is because the audio output of the Filtrex-II is impedance balanced and requires three connections to the outside world. The stereo one is therefore not being used to carry a stereo signal but a TRS or tip-ring-sleeve connection. We can use this like we would a true balanced output signal but with full compatibility with ordinary unbalanced connections too.

The ground pin on each header is always on the right hand side as you look at the board with the pots facing forwards. This is pin 1 of the header so the ground pin should correspond to the square pad on the PCB. Each of these pads will be connected to the respective jack socket's ground pin, ie. the one that will connect to the barrel of the plug when it is inserted.

On the two pin headers the signal is sent on the furthest left pin of the header, pin 2 on the two way headers and pin 3 on the three way header.

For each mono socket, it is a good idea to twist the wires together in pairs. Use two different colours to tell them apart, and try to keep the wiring as short as possible to prevent picking up hum and other stray fields. You can use screened cable if you wish, and this should be so if you are using a wooden case to house the Filtrex. The screen must go to pin 1 of each 2-way header as it carries the ground. Pin 1 should thus connect to the socket's sleeve terminal. Pin 2 should connect to the tip terminal of the socket.

For the stereo (TRS) socket you have three connections to make. If you are wanting to use screened cable you will need to use special balanced cable which comes with a single screen that overlaps two identical conductors. Like the other connections pin 1 is the ground and should be connected to any shield if you are using screened cable. As before this should go to the sleeve lug of the socket. The audio signal is carried from pin 3 of the header and this should connect to the tip lug of the socket. Pin 2 is the ground compensation input and should connect to the ring of the output socket.

I recommend that you use plastic sockets and not ones with a metal mounting bush. This allows any metal case to float electrically with respect to the socket's ground connection. However, I do recommend you ground your case in a controlled manner as this will reduce the likelihood of picking up radiated hum fields from other pieces of equipment and wiring. What we need to do is tie our case to 0V but not tightly. R126 and the 'CASE' solder pad provide an easy way of doing this.

Fit a M4 bolt through the rear panel of your metal case. With a washer, spring washer and nut, fasten a solder tag to it. Solder a piece of insulated wire from the tag to the solder pad 'CASE' on the PCB. Your case is now grounded.

If you are mounting your PCB to the case via the M3 mounting holes in the top left and top right of the PCB then you do not need to use the CASE pad. The top right hole, the one next to the CASE pad, is connected directly to the CASE pad. By simply bolting the board to your case with metal hardware you will ensure your case is adequately grounded.

If you have used metal sockets then you don't need to ground your case via the 'CASE' pad since your case will be grounded very tightly via all the sockets. However, this **may** cause earth loop problems if you then mount your case into a rack with other pieces of equipment in it.

Please note that grounding a case is not the same as earthing a case. Your case must be additionally earthed if you are fitting an internal mains transformer into your case. Please see the next section for some more details on this.

Power Supply and Power Supply Connections

The recommended option is to use an insulated plugtop (often called a wallwart) AC adapter. They are used external to the Filtrex housing and plug into the Filtrex using the two pole barrel connector. They are very safe since all the dangerous high voltage stuff is kept inside the wall-wart.

You need a 15V or 18V alternating current (AC) output at 250mA or higher rating. Do not use a DC output type. Although the latter are the most common type of wallwart for guitar effects pedals, they will not work with the Filtrex. To reiterate, because this is really important, it must say 15VAC or 18VAC on it somewhere.

Finding such a power supply is not always as easy as it should be. So many plugtop supplies these days are switch mode DC output types. However, unregulated AC output ones are out there and most decent electronic parts suppliers will have them, as well as online guitar effects shops and even some music shops. Since a wallwart supply will have its own mains plug built into the case it's not practical for me to list an example for every country out there. In addition listing a part number for a generic power supply is a bit like a game of whack-a-mole as the moment I give the part number that very part will disappear and a new one with a different part number will appear. If you do get stuck it may be best to ask on the forum and see what other members suggest. That said if you are in the UK and have a Farnell account you could try their part number: 2368009.

Some 12V AC output types may also work but this is only because some AC output wallwarts tend to be poorly regulated and have a lot of overhead. Do be aware that if they do work some of the time they may not work all of the time. If the voltage does fall below the required operating voltage of the Filtrex-II the most obvious sign is an audible hum from the outputs. You will not damage the Filtrex-II by doing this although any connected amplifier or speaker system may object to the humming.

To connect your wall wart to the Filtrex you need a suitable chassis mounting connector. You must ensure you get one that has a plastic housing and plastic mounting bush. This means that there should be no electrical contact between the case and the power socket. Do not get one that has a metal mounting bush as this will inevitably connect one of the AC connections directly to the case.

Make sure too that you get the right socket for the plug you have on the wall wart. Some wall warts give you a little bundle of different types to choose from. Ensure that the socket you get allows the plug to slip in easily yet not break connection when wiggled gently. If you are making up your own plug for it, since it is AC, it does not matter which wire goes to what. There is no + or -.

Once fitted to your case the socket must then be connected to the PCB. One terminal goes to AC1 and the other goes to AC2 on the PCB. If your wires are longer than 100mm or so then it is a good idea to twist them together. This reduces the amount of radiated noise from the wiring.

AC3 and AC0 are left unconnected.

Internal Mains Transformer

The following advice is only for those who know how to wire mains rated equipment safely. If you do not know how to do this then make no attempt to do so. I do not endorse this method of powering any Oakley equipment. It is up to you to use your PCB wisely. I take absolutely no responsibility for your actions with this board. I will offer no further advice than what you see here in italics:

Transformer rating: Secondaries: 18-0-18 @ 250mA or 18-0, 18-0 @ approx 15VA total

Connect common, or centre tap, to AC1 and/or AC0. Others to AC2 and AC3.

Line fuse: T250mA

Any metal case must be earthed directly from the mains inlet socket with a thick piece of wire and suitable bonding point on the case.

0V on the board should also be tied to earth using a piece of wire connecting the earth bonding point and the 'CASE' solder pad on the board. R126 should be a wire link and not a resistor.

Powering the Filtrex with the MOTM header

The Filtrex may also be powered from the MOTM or Oakley power busses. The power socket is 0.156" Molex/MTA 4-way header is marked as MOTM on the PCB. Friction lock types are recommended. The pin out is as follows:

Power	Pin number
+15V	1
Module GND	2
Module GND	3
15V	4

Pin one is depicted by the diagonal on the legending. If you are using the MOTM system to power your Filtrex, be sure not to fit the following components which make up the Filtrex's own +/-15V regulated supply:

U15, U11, D13, D14, D18, D19, D9, D24, C40, C47, C38, C50

You can also use the Filtrex to power other MOTM/Oakley modules using the MOTM header. However, be sure not to exceed the power rating of the wallwart, transformer, heatsinks and smoothing capacitors.

Trimmers

TRIM: Adjust this trimmer so that the filter bursts into oscillation when the ‘resonance’ pot is moved close to its maximum setting. The filter should oscillate from about 100Hz to over the range of your hearing. Or you can adjust it so that it never goes into oscillation at all. This will prevent you from accidentally damaging your ears, your tweeters and upsetting your neighbour’s dogs. But hey, that would be boring. Live life in the fast lane. Trim it up so that it just oscillates when the resonance is up full.

BAL: Listen to the ‘Smooth’ output. Set the Resonance and Frequency pots to their mid positions. Turn the LFO modulation depth pot to its maximum value and select the triangle wave. Adjust BAL until the clicking or buzzing becomes minimised.

Housing your unit

The PCB has been designed to fit into a standard 1U high 19" rack unit. Your local parts distributor will probably have these. Good rack units are quite expensive, and will contribute heavily to the final cost of your completed Filtrex. Expect to pay around 35GBP or so.

In the UK the ones I recommend are made by Bryant Broadcasting or Holt Broadcasting Services. You can use the Schaeffer Frontplatten database provided on the project webpage as a template for any drilling of holes in the front panel.

The Bryant and Holt ones are superbly made, but they do not allow you to use a 3mm thick Schaeffer front panel in place of their own. Their cases actually utilise the front panel as part of the enclosure. Simply swapping the Bryant or Holt panel with one obtained from Schaeffer will not work as the case would no longer be able to held together. Bryant and Holt do custom metal work, so it may be possible to try their services. This is one area I would like to try in the near future.

Schaeffer, and their US franchise Front Panel Express, are also able to engrave panels that are sent to them. One could send them the blank Bryant panel and they could engrave this with the Frontplatten database found on the Filtrex website. I have heard from one person who has tried this and he was very pleased with the result. Remember if you do decide to do this, you must remove the four mounting holes from the Frontplatten database before sending it to Schaeffer or Front Panel Express as these are already present on the Bryant panel. I am not sure whether this could be successfully done with the grey painted finish of the Holt panels.

A Schaeffer FPD file can be found on the Filtrex's project webpage which can be downloaded and edited. If printed out at 100% size and in 'wire mode' with reference points, you can then use it as a template for drilling your own front panel holes.

My current favourite method of labelling a front panel on one of these empty rack cases is to use a thin (1.5mm) engraved black anodised aluminium 'overlay' panel from Schaeffer. This is held onto the main case's front panel by three or more 3mm screws at suitable points along overlay and the components simply stick out the holes in the overlay. The pot nuts are secured to the front panel of the rack case which hold the board in place. Once the PCB is fitted and tested the overlay can then be secured into place. The pot holes in the overlay will need to be sufficiently large enough not to snag on the pot nuts and washers and the FPD should be edited accordingly. I use 14mm diameter holes in the overlay which are big enough to not foul the pot nuts but are small enough to be nicely covered up by the control knobs. The LED holes need to be 3.2mm and the switch hole 7mm.

If you buy the rack cases made by Vero, you will find that the height of the unit internally is quite restricting. The bottom and lower panels have 6mm folds in them at the front. This affects the amount of space available for the pots and circuit board at the front panel. It is possible to use these cases as I have done in the past but you will need to mount the board high enough on the front panel to prevent the pot pins shorting with the case.

The other thing to beware is the heatsinks. Don't let either one of them touch the top panel, since this would cause major problems. This shouldn't happen if you make sure the base of the regulators ICs are fitted within 10mm of the PCB.

For those of you fitting an internal toroidal transformer you must make sure there is no way the bolt that secures the transformer can touch both the bottom and top of the metal case. If the metal support of transformer together with the case makes a complete loop around the core, then you have a shorted one turn secondary. ('Well, there was a large hum, more of a buzzy rattle really, then a smell of burning rubber and then a lot of smoke... '). You may also like to consider the use of a nylon bolt to hold the transformer in place.

When an internal transformer, toroid or otherwise, is being used then the metal case **must be connected securely to earth**. This is best done with a M4 bolt, nut, toothed washer and solder tag directly wired (with thick wire) to the IEC inlet socket's earth tag. The Filtrex's circuitry should be then tied to earth as detailed in the power supply section in this document. Once again I should stress that building a component level mains transformer into any DIY project should not be taken lightly as the consequences for getting it wrong can be severe.

The PCB will be supported well enough by the pots and pot brackets. However, this may give some people nightmares so it for them it will be a good idea to provide additional support. Small holes, to fit M3 bolts, have been provided on the outer corners of the PCB to do this. Feel free to enlarge these holes if you wish. My prototype has been very happy just supported by the pots. However, my unit doesn't get moved around much. If you intend to take it out on the road, extra support may be a good idea.

Stereo processing with two Filtrex-II modules – Application Hints

Author's note: I haven't tried this yet with the Filtrex-II, however, the theory is sound so it should work without issue. I would be interested in hearing from people who have made a dual unit. Feel free to contact me either directly by e-mail or via the Forum.

Two Filtrex PCBs must be populated. One should be designated Master and one Slave. The slave one is identical to the master except that it has no onboard power supply. The slave receives its power from the master using the MOTM headers.

The two 2-pin headers, STV and ST-A, must also be fitted to both boards. STV is an abbreviation of 'stereo voltage' and ST-A is for 'stereo-audio'. STV will carry the filter cut-off CV from the master to the slave. ST-A will carry an audio signal from the slave to the master.

You will also need two SPST (or SPDT) switches, or one DPST (or DPDT) switch, somewhere on your front panel. This will give you the option of switching between two completely independent Filtrex channels and one stereo dual Filtrex.

I would expect any dual Filtrex to be fitted to a 2U high rack case. The master would be the upper one and the slave below it. Use the MOTM header to carry power from the master to the slave. I would recommend using Amphenol 0.156" MTA connections since the wires from these come out at right angles to the connector and are therefore lower profile. The PCB has been designed so when using MTA connectors the wires move away from the front of the board so can be looped from one board to the other.

The heatsinks fitted to U11 and U15 must be closely monitored after first building up a stereo unit. When being run from a 15V AC wallwart the heatsinks get only slightly warm when driving a single Filtrex-II. But doubling the power output of the power supply will double the power dissipation in those regulators. Therefore you may wish to increase the size of the heatsinks. The Filtrex-II PCB has been designed to accommodate larger heatsinks than the standard ones.

To link the two Filtrexes together you need to allow the CV signal from the master Filtrex to affect the cut-off frequency of the slave. To do this connect pin 1 of STV on the master to pin 2 of STV on the slave. Wire your switch so that this signal can be broken by the action of opening the switch.

To allow the master's envelope follower and threshold detector circuit to work from the slave's audio input or side channel, that audio signal must be passed up into the master's side channel amplifier based around U14a. To do this connect pin 1 of ST-A on the slave to pin 2 of ST-A on the master. Again, wire your switch so that the connection can be broken when the switch is opened.

You can switch STV and ST-A together with a DPST (or DPDT) switch, or you can switch each independently with a SPST (or SPDT) switch. One switch lends itself to a simpler front panel design but there may be times when you want the master to not listen to what the slave is processing.

Final Comments

If you have any problems with the module, an excellent source of support is the Oakley Sound Forum at Muffwiggler.com. Paul Darlow and I are on this group, as well as many other users and builders of Oakley modules.

If you can't get your project to work, then Oakley Sound Systems are able to offer a 'get you working' service. If you wish to take up this service please e-mail me, Tony Allgood, at my contact e-mail address found on the website. I can service either fully populated PCBs or whole modules. You will be charged for all postage costs, any parts used and my time at 25GBP per hour. Most faults can be found and fixed within one hour, and I normally return modules within a week. The minimum charge is 25GBP plus return postage costs.

If you have a comment about this user guide, or have found a mistake in it, then please do let me know. But please do not contact me or Paul Darlow directly with questions about sourcing components or general fault finding. Honestly, we would love to help but we do not have the time to help everyone individually by e-mail.

Last but not least, can I say a big thank you to all of you who helped and inspired me. Thanks especially to all those nice people on Muff's Forum and the Synth-diy and Analogue Heaven mailing lists.

Tony Allgood at Oakley Sound

Cumbria, UK

© June 2012 – updated September 2016

No part of this document may be copied by whatever means without my permission.